

Erreichen auf	Maximum	Maximum	Minimum	Maximum
Bandbreite	BF2 - 5-5	BF3 - 6-9	Neutra - Trimmer	BF 1-4-7
± 3 kHz	C3 (im Becher)	C1 (im Becher)	C13 - 47 - 81	_____
± 15 kHz	C5 - 39 - 73	C23 - 57 - 91	C14 - 48 - 82	_____
± 500 Hz	C6 - 40 - 74	C24 - 58 - 92	C16 - 50 - 84	_____
± 250 Hz	C8 - 42 - 76	C26 - 60 - 94	C16 - 52 - 86	_____
± 100 Hz	C10 - 44 - 78	C28 - 62 - 96	C20 - 54 - 88	_____
± 6 kHz	C5 (im Becher)	C4 (im Becher)	_____	L1 (im Becher)

