



ECC 81

Rö 1, 10, 11  
15, 16, 18  
21, 26  
29




E 180 F

Rö 2, 7  
27, 28




EF 804 S

Rö 12, 32




EL 84  
EL 86

Rö 19, 30, 31




E 88 CC

Rö 8, 9




EL 95

Rö 35




EAA 91 (EB 91)

Rö 17






MW 36-44

Rö 13





85 A2

Rö 33, 34



EF 86

Rö 14, 20



- a Wobblersenderausg. → Markengren
- b + 85 V (Stabilisator Rö 32 → g2 Rö 12)
- d 4000 V Hochspannung → Bildröhre + 250 V stabilisiert!
- e -180V unstab, Gl 6 → R 19
- f +400V unstab, a Rö 11 → a Rö 30 + Rö 31

